

Drive safe. Drive confident.

1300 789 908 | www.easyclick.com.au

Designed, developed and manufactured in Australia by Alcolizer Technology – the largest supplier of alcohol detection equipment to Australian law enforcement.

Alcolizer
easy check

Returning your Easy Check for calibration

Your Easy Check is a precision calibrated instrument which requires periodic calibration to maintain its accuracy. For your own safety, return the device to Alcolizer Technology or an Alcolizer authorised certified calibration centre every six months.

The display will show 'RECAL' when calibration is due. Return your Easy Check, by following these steps:

1. Fill in the supplied Calibration Request form, or book easily online at: www.easyclick.com.au
2. Place your Easy Check inside its hard carry case for postage protection.
3. Place your Easy Check inside a box or courier bag and please provide your return address, phone number and email address.
4. Dispatch of your device through your local postal service or courier.
5. Your Easy Check will be inspected, serviced, calibrated and tested for accuracy by qualified technicians.
6. Expect the return of your Easy Check within a few days!

Warranty

Your Easy Check personal breathalyser is guaranteed to be free from defects in workmanship and materials for 24 months from the date of purchase.

Alcolizer Technology will repair or replace your unit, at its discretion, subject to the following:

- You must either return the supplied Warranty Registration Card within 30 days from date of purchase or visit the following link to submit online: www.easyclick.com.au
- Damage through misuse or wear and tear is not covered by warranty.
- The serial number seal must not be damaged or removed or it will void warranty.

For full warranty terms and conditions visit: www.alcolizer.com/warranty-registration

Warranty Claims

To make a warranty claim, your Easy Check must be returned to Alcolizer Technology or your closest distributor, (refer to the website for nearest distributor) at your expense.

Disclaimer

The breath alcohol (BAC) reading obtained by correct use of this unit is considered accurate only at the time you test yourself.

Neither the manufacturer, distributor nor retailer accepts any liability or responsibility in respect of your use of this information.



**Drive safe.
Drive confident.**

1300 789 908
www.easyclick.com.au



Getting the most out of your Easy Check

- It is recommended to not consume alcohol, eat, use mouthwash or breath spray for 15 minutes prior to testing.
- Breath Alcohol Concentration (BAC) can rise for up to two hours after last drink. Re-test if in doubt.
- It may take 10 hours or more for a high BAC level to return to zero. Further testing later in the day or the next morning is recommended.
- Calibration is required after six months. Easy Check will display 'RECAL'. You cannot use the breathalyser until it is calibrated.
- Do not store unit in places where moisture or extreme temperature conditions can occur.

Power Usage/ Batteries

Easy Check is powered by x2 Alkaline batteries (AAA). Do not replace batteries - this is done during calibration. Removal of batteries will incur loss of calibration and warranty. Note: When not in use, the back light will turn off and the device will go into low power standby mode.

Steps to conduct an Easy Check test:

1. Fit a mouthpiece onto the inlet located on the (front) left side of the device.
2. Ensure the top-left of the screen displays 'READY' – you can then press the button to conduct a test.
3. Easy Check will display an animation whilst it conducts a quick self-check.
4. When the display shows 'blo', take a deep breath, and blow steadily into the mouthpiece. Short beeps will sound while blowing. Continue to blow until a click and short musical tone is heard.
5. After a few seconds, your result will be displayed – Example: '.030g/100ml'.
Note: If you do not blow within 15 seconds, or hard or long enough a musical tone will sound and the message, 'TRY AGAIN' will be displayed. Repeat step 2 onwards to try again.

Recovery period is usually less than one minute but recovery may take longer after a high BAC reading.

Easy Check will be ready for a new test when its recovery period is complete and the 'READY' message is displayed.

Excessive Readings

The display will flash if your reading exceeds the device limit of .300g/100ml.

Other Functions

Press and hold the button to display the following information:

- The last reading
- The number of tests remaining till calibration
- The number of days before calibration is due

The information will continue to be displayed, in sequence for three seconds each, for as long as the button is pressed.

Display Illumination

The display light automatically turns off after a few seconds.

If the result is displaying but 'READY' is not yet displayed, turn the display light on again by briefly pressing the button.

Note: When the Easy Check is in low power standby mode (not backlit), it will display 'READY' at the top-left of the screen and also the last BAC test result.