

Alcolizer

HH3 alcohol tester



INDUSTRIAL GRADE HANDHELD ALCOHOL TESTER

- ✓ Rugged and proven to perform
- ✓ Multi-function testing
- ✓ USB data download
- ✓ Simple, easy to use menu screens
- ✓ Outstanding value, entry level instrument

Developed for small to medium-sized enterprises, the Alcolizer HH3 is outstanding value and ideal for companies starting workplace alcohol testing.

PROVEN PERFORMANCE, HIGH GRADE

The Alcolizer HH3 has a highly responsive platinum electrochemical fuel cell that delivers capable, fast and accurate results in both commercial and industrial applications.

MULTI-FUNCTION TESTING

Performs both Standard Mouthpiece and Passive tests to suit any workplace and Drug and Alcohol testing program.

DURABLE AND CAPABLE

Developed for heavy duty conditions, the Alcolizer HH3 has a robust, shock resistant casing delivering durability and reliability in commercial, industrial and remote environments.

EASY USB DATA DOWNLOAD

Utilise AlcoCONNECT™ Toolbox software for easy test data download and analysis from your HH3 Alcohol Tester.

Filter test data to your requirements then easily export in CSV format to assist your workplace compliance.

SERVICE AND SUPPORT

Each HH3 Alcohol Tester is backed by a 36 month warranty and is supported by the AlcoCARE™ program. Our global network of service providers and factory trained technicians provides rapid return calibration and expert customer support.

CALIBRATION

HH3 requires calibration every twelve months as per Australian Standards Certification requirement.

HH3 will display a warning message after switch on if 28 days or less remain before calibration is required.

Alcolizer Technology will also contact you with a friendly reminder to send your HH3 into your nearest Alcolizer Certified Calibration & Servicing Centre for prompt calibration.



STANDARD FEATURES

- Multi-function capability for both Standard Mouthpiece and Passive testing
- Highly responsive, law enforcement grade platinum electrochemical fuel cell
- Data download of 30,000+ logs
- Unlimited tests
- Multi-language capability
- Transreflective mono screen
- 36 month warranty
- AlcoCONNECT™ Toolbox
- AC/DC charger
- USB data download cable
- Proudly designed, developed and made in Australia by Alcolizer Technology to AS3547:2019 Certification Type 2. Alcolizer Technology is an ISO 9001:2015 Certified company.

OPTIONS

- Mouthpieces: standard or non-return valve saliva trap
- Hard durable carry cases – either for one or multiple Alcolizer instruments, consumables and accessories
- Soft shoulder bag
- Vehicle charger
- Wrist lanyard



TECHNICAL SPECIFICATIONS

INSTRUMENT APPLICATION	▶ Commercial and Industry
SENSOR TYPE	▶ Law enforcement grade, highly responsive platinum electrochemical fuel cell
ACCURACY	▶ As per Australian Standard AS3547:2019
BrAC RANGE	▶ 0.000 – 0.462g/210L (BrAC) result
TEST TIME	▶ Within 3-5 seconds for a 0.100% BrAC result
RECOVERY TIME	▶ Instant for 0.000 BrAC readings (retained on-screen for 10 seconds)
DISPLAY	▶ Transreflective mono graphics screen display
MOUTHPIECE	▶ Standard spigot locator or non-return valve
CALIBRATION	▶ 12 month back-to-base calibration at an Alcolizer Certified service facility
OPERATING TEMPERATURE	▶ Range -5°C to 55°C
POWER SUPPLY	▶ Rechargeable Li-Ion battery system
WEIGHT	▶ 272g (including battery)
DIMENSIONS	▶ 202mm H x 63mm W x 39mm D

AlcoCARE

AlcoCARE™ is a customer support service that provides fast, professional product and technical support for all your Alcolizer products, either on-site or through our efficient return-to-base calibration and support service centre network.

AlcoTRAIN

Alcolizer's dedicated AlcoTRAIN team focus on developing leading-edge training programs for a wide variety of applications.

In addition to the standard training programs, we welcome enquiries to discuss custom training and have a reputation for designing training and educational content to match unique customer needs.

Contact any of our nationwide offices by calling **1300 789 908** or email sales@alcolizer.com



V300.02.100621