

Wall Mount 4

alcohol tester

INDUSTRY'S MOST ACCURATE WALL MOUNT BREATH TESTER

- ✓ Fast testing of high volume workforces
- ✓ Efficient, reliable, durable operation
- ✓ Highly configurable to your Drug and Alcohol program
- ✓ Instant results delivered to management
- ✓ Self calibrating every 24 hours
- ✓ Serviced by factory trained technicians



Alcolizer Wall Mount 4 delivers superior breath testing solutions and is trusted by commercial and heavy use industrial customers around the world.

KEEP YOUR WORKFORCE AT WORK WITH ACCURATE, FAST READINGS

Alcolizer Wall Mount 4 (WM4) operates 24 hours a day in conditions ranging from 0°C to 40°C. With on-board NATA Certified gas and daily auto self-calibration, WM4 is arguably the most accurate alcohol breath tester, day-in, day-out anywhere in the world. Australian Standards certifies Alcolizer to service annually and still comply to AS3547:2019.

WM4 processes up to 240 workers an hour with an instant response time on a zero BrAC test. WM4 is the only wall mounted breath tester on the market today running unparalleled connectivity options supported “out-of-the-box” with a Programmable Colour Screen.

WM4 integrates with various third party workforce management and access control solutions via connectivity including (but not limited to): Keypad, Swipe card, WIEGAND, Live Secure Reporting, USB and multiple RS232 ports.

SERVICE AND SUPPORT

A network of established factory trained service technicians and Alcolizer authorised distributors are available to provide expert support. We know our equipment is a critical component in ensuring the health and safety of your workers, site visitors and assets.

Our AlcoCARE™ program and our factory trained technicians can support your equipment either on-site or back-to-base – whichever is faster and most cost-effective for you.

SITE CONFIGURABLE TO SUIT YOUR DRUG & ALCOHOL PROGRAM

Designed to support your Drug and Alcohol programs, WM4 is highly configurable from simple self-test stations to comprehensive alcohol test sign-in systems.

WM4 integrates with your site management system and delivers relevant data live to your desktop by sending an email when an exception test occurs.

STANDARD FEATURES

- Self calibrates every 24hours
- Instant recovery for zero test
- Unlimited testing
- Ethernet interface
- RS232 serial ports
- 24 month warranty
- Colour LCD display
- Strong durable transit case
- LAN connectivity in every model
- Customisable screen messages
- ISO 9001:2015 Certified Company
- Developed and manufactured to AS3547:2019

UPGRADE OPTIONS

- Numeric key pad
- QR Code Reader
- Swipe Card Reader
- Identification camera
- Cellular data connection
- Printer – Paper and label types
- AlcoCONNECT™ Data Management

AlcoCONNECT™ Data Management – the ideal tool for Safety and Business Managers seeking real-time test results.
Enable with AlcoCONNECT™ Live Data Management system.

- ✓ Customise data collection
- ✓ Easy input to identify test events and staff
- ✓ Quickly identify staff with NFC or QR codes
- ✓ Print test records on the spot
- ✓ Supervised or unsupervised testing
- ✓ Photographic evidence



ACCESSORIES AVAILABLE



TECHNICAL SPECIFICATIONS

INSTRUMENT APPLICATION	▶ Industry
BrAC RANGE	▶ 0.000 – 0.462g/210L (BrAC)
ACCURACY	▶ As per Australian Standard AS3547:2019
RECOVERY TIME	▶ Instant for 0.000 BrAC readings (retained on-screen for 10 seconds)
DISPLAY	▶ Three decimal BrAC reading on 25cm (10”) colour graphics LCD screen
SENSOR	▶ Law enforcement grade, highly responsive electrochemical fuel cell
MOUTHPIECE	▶ Standard straws
POWER SUPPLY	▶ 100-240V ~50/60Hz 75W
WEIGHT	▶ 18kg
DIMENSIONS	▶ 560mm H x 390mm W x 190mm D
CALIBRATION	▶ Automatic calibration every 24 hours (NATA certified gas)
OPERATING TEMPERATURE	▶ RANGE 0°C to 40°C
RESULTS NOTIFICATION	▶ Email reporting and alerts
CONNECTIVITY	▶ Multiple connectivity and integration options

SERVICE & SUPPORT FROM THE ORIGINAL EQUIPMENT MANUFACTURER

Alcohol breath test units are a critical component in the management of the health and safety of companies, personnel and site visitors.

AlcoCARE™ is a customer support service that provides fast, professional product and technical support for your Alcolizer products, on-site or through our efficient return-to-base calibration in our service centre.

Our technicians are factory certified and trained under the guidance of the original engineering design team.



ALCOCARE™ STANDARD

Service charge plus parts and a 90 day limited warranty.

ALCOCARE™ PREMIUM

Includes labour, parts and a Lifetime Warranty with return to base service option or on-site service option.



V700.1.030321

Contact any of our nationwide offices by calling **1300 789 908** or email **sales@alcolizer.com**