

Easy Check Personal Use Breathalyser



Electrochemical fuel cell technology



24 month warranty



On-screen recalibration notification



Rapid zero testing recovery



Australian Standards Certified AS3547 Type 2



Free software upgrades on calibration (If serviced & calibrated by Alcolizer Technology)



Alcolizer
easy check

Alcolizer Technology
1300 789 908
sales@alcolizer.com

Manufactured to the highest quality standard (ISO9001:2015) Australian Standard AS 3547 (Type 2), the Easy Check is the smart choice for personal users

The Alcolizer Easy Check (EC) is the personal breath alcohol test unit relied on by thousands to keep them safe.

The Easy Check Series offers police standard electrochemical fuel cell sensing technology while a vast majority of 'personal breath testers' in the market use low cost semi-conductor sensors or cheap, low grade manufactured fuel cells. Alcolizer chooses to exclusively use the highest-grade platinum fuel cells for all of our products, including the Easy Check Series.

Technical Specifications

SENSOR TYPE	▶ Platinum electrochemical fuel cell
ACCURACY	▶ AS per Australian Standard AS3547:1997
BAC RANGE	▶ 0.000 - 0.300 BAC
TEST TIME	▶ Up to 10 seconds
CALIBRATION	▶ Back to Base, every 6 months
TEST LIMIT	▶ Up to 2,000 tests

Service and Calibration

When 6 months arrives from the date of your Easy Check purchase, send in your device (following the three easy steps shown on the right).



All inclusive Service and Calibration
NO HIDDEN POSTAGE COSTS

Booking your Easy Check Calibration

IN JUST THREE EASY STEPS

STEP 1

Jump online and visit alcolizer.com/product/ec-calibration



STEP 2

Book your calibration – Have your device Serial Number and Purchase Order number handy (if you have an account with us) and provide your credit card details.



STEP 3

After booking your calibration online, post the device to the Service Centre below and we will calibrate and return it to you.



Send your Easy Check to:

Alcolizer Technology
36 Mumford Place
Balcatta, Perth WA 6021
Western Australia

For international servicing requirements, please contact your local Alcolizer Certified Service & Distribution centre.

Visit alcolizer.com/international to find your closest location



Quality
ISO 9001

SAI GLOBAL

For all your Alcohol & Drug Testing Requirements
Ph 1300 789 908
sales@alcolizer.com
www.alcolizer.com

V4



Alcolizer
technology

TRUSTED ALWAYS