

Alcolizer HH3 Alcohol Tester



Industrial grade, proven performer with multi function testing



Annual servicing with 36 month warranty



Electronic result display, no interpretation, USB data download



Multi-function capability standard & passive testing



Verified to Australian Standard AS 3547:2019 (certification type 2)



AlcoCONNECT™ Live and OST App compatible



Developed for small - medium sized enterprises, offering outstanding value, ideal for companies starting workplace alcohol testing.

Device Features

- Multi-function capabilities for Standard Mouthpiece & Passive testing
- Law enforcement grade platinum electrochemical fuel cell
- Data download of 30,000+ logs with unlimited tests
- Multi-language capability, transreflective mono screen
- AlcoCONNECT™ Toolbox
- Proudly designed, developed and made in Australia by Alcolizer Technology to AS3547:2019 certification type 2.
- Alcolizer Technology is an ISO 9001:2015 Certified company.

Technical Specifications

INSTRUMENT APPLICATION	▶ Commercial & Industry
SENSOR TYPE	▶ Law enforcement grade, highly responsive platinum electrochemical fuel cell
STANDARD	▶ Designed to Australian Standards AS 3547:2019
BrAC RANGE	▶ 0.000 – 0.462g/210L (BrAC) result
TEST TIME	▶ Within 3-5secs for 0.100% BrAC result
RECOVERY TIME	▶ Instant for 0.000 BrAC readings (retained on-screen for 10 seconds)
DISPLAY	▶ Transreflective mono graphics screen display
MOUTHPIECE	▶ Standard spigot locator or non-return valve
CALIBRATION	▶ 12 month back-to-base calibration at an Alcolizer Certified service facility
OPERATING TEMPERATURE	▶ Range -5°C to 55°C
POWER SUPPLY	▶ Rechargeable Li-Ion battery system
WEIGHT	▶ 272g (including battery)
DIMENSIONS	▶ 202mm H x 63mm W x 39mm D

Why Alcolizer HH3?



PROVEN PERFORMANCE, HIGH GRADE

The Alcolizer HH3 has a highly responsive platinum electrochemical fuel cell that delivers capable, fast and accurate results in both commercial and industrial applications.



MULTI-FUNCTION TESTING

Performs both Standard Mouthpiece and Passive tests to suit any workplace and Drug and Alcohol testing program.



DURABLE & CAPABLE

Developed for heavy duty conditions, the Alcolizer HH3 has a robust, shock resistant casing delivering durability and reliability in commercial, industrial and remote environments.



EASY DATA DOWNLOAD & REPORTING

Utilise AlcoCONNECT™ Toolbox software for easy test data download and analysis from your HH3 Alcohol Tester.

Filter test data to your requirements then easily export in CSV format to assist your workplace compliance.



SERVICE AND SUPPORT

All HH3 Alcohol Testers are backed by a 36 month warranty and is supported by the AlcoCARE™ program.

Our global network of service providers and factory trained technicians provides rapid return calibration and expert customer support.



CALIBRATION

Requires 12 monthly calibration as per Australian Standards Certification requirements.

The HH3 will display a warning message (from 28 days until calibration due). We will also contact you with a friendly reminder to send your HH3 in for prompt calibration.



Quality
ISO 9001



For all your Alcohol & Drug Testing Requirements

Ph 1300 789 908

sales@alcolizer.com

www.alcolizer.com

v3



Alcolizer
technology

TRUSTED ALWAYS