

Alcolizer HH4 Alcohol Tester



Industrial grade, proven performer with multi function testing



Electronic result display, no interpretation, USB data download



Verified to Australian Standard AS 3547:2019 (certification type 2)



Annual servicing with 36 month warranty



Multi-function capability standard & passive testing



AlcoCONNECT™ Live and OST App compatible



The ideal tool for Safety and Business Managers seeking real-time mobile enhanced test results.

Device Features

- Multi-function capabilities for Standard Mouthpiece & Passive testing
- Law enforcement grade platinum electrochemical fuel cell
- Data download of 30,000+ logs with unlimited tests
- Transreflective colour LCD screen
- AlcoCONNECT™ Toolbox
- Proudly designed, developed and made in Australia by Alcolizer Technology to AS3547:2019 certification type 2.
- Alcolizer Technology is an ISO 9001:2015 Certified company.

Technical Specifications

INSTRUMENT APPLICATION	▶ Commercial & Industry
SENSOR TYPE	▶ Law enforcement grade, highly responsive platinum electrochemical fuel cell
STANDARD	▶ Designed to Australian Standards AS 3547:2019
BrAC RANGE	▶ 0.000 – 0.462g/210L (BrAC) result
TEST TIME	▶ Within 3-5secs for 0.100% BrAC result
RECOVERY TIME	▶ Instant for 0.000 BrAC readings (retained on-screen for 5 seconds)
DISPLAY	▶ Transreflective colour graphics LCD screen
MOUTHPIECE	▶ Standard spigot locator or non-return valve
CALIBRATION	▶ 12 month back-to-base calibration at an Alcolizer Certified service facility
OPERATING TEMPERATURE	▶ Range -5°C to 55°C
POWER SUPPLY	▶ Rechargeable Li-Ion battery system
WEIGHT	▶ 272g (including battery)
DIMENSIONS	▶ 202mm H x 63mm W x 39mm D V4

Why Alcolizer HH3?



LAW ENFORCEMENT GRADE

The Alcolizer HH4 has a highly responsive platinum electrochemical fuel cell that delivers capable, fast and accurate results in both heavy industry and law enforcement applications.



MULTI-FUNCTION TESTING

Performs both Active (mouthpiece) and Passive tests using – Pressure-Activated Passive Testing and Fast-Passive Testing.

Pressure-Activated is automatically activated by breath pressure provided by a test subject. Fast-Passive is a new, faster response time for Passive Testing.



DURABLE & CAPABLE

Developed for heavy duty conditions, the Alcolizer HH4 has a robust, shock resistant casing delivering durability and reliability in commercial, industrial and remote environments.



CONNECTED FOR MAXIMUM CAPABILITY

Multiple connectivity options include, bluetooth printing and AlcoCONNECT™ Toolbox for data download. Sync stored results to AlcoCONNECT™ the complete solution to access live analysed results from any device.



SERVICE AND SUPPORT

Backed by a 36 month warranty and supported by our AlcoCARE™ program. Our global network of service providers and factory trained technicians provides rapid return calibration and expert customer support.



CALIBRATION

Requires 12 monthly calibration as per Australian Standards Certification requirements.

The HH4 will display a warning message (from 28 days until calibration due). We will also contact you with a friendly reminder to send your HH3 in for prompt calibration.



Quality
ISO 9001

SAI GLOBAL

For all your Alcohol & Drug Testing Requirements
Ph 1300 789 908
sales@alcolizer.com
www.alcolizer.com

V4



Alcolizer
technology

TRUSTED ALWAYS